INSTALLATION INSTRUCTIONS FOR C-3503-DM

Prepare Valve for Installation:

- 1. Make sure that valve spool and valve face are free of any foreign particles.
- 2. Remove retaining ring from shaft (discard).
- 3. Remove the two 1/4-20 capscrews holding the seal retaining flanges in place remove flanges and o-ring on shaft.

Prepare Cylinder for Installation:

- 1. Remove the two 5/16-18 capscrews from rear of cylinder. This will disassemble cylinder into 3 pieces:
 - 1) Mounting Bracket with Sockethead Capscrews
 - 2) Cylinder Body Assembly with O-Ring
 - 3) Rear Cover Plate with O-Ring

<u>Installation of Cylinder:</u>

- 1. Slide bracket over shaft with recess of bracket facing pump. Make sure O-Ring seat is in recess of bracket. Attach to pump with (2) sockethead capscrews using a 3/16" allen wrench.
- 2. Rotate pump shaft to align hole in shaft with the setscrew located inside the middle air port of the cylinder body. Slide cylinder body assembly over shaft.
- 3. Apply Loctite to setscrew and secure to pump by screwing setscrew through pump shaft using a 5/32" allen wrench, tighten firmly.
- 4. Place rear cover plate with O-Ring onto end of cylinder body and install capscrews, torque to 10ft/lbs.
- 5. Test alignment of cylinder by removing pipe plug from rear cover, inserting a 3/16" allen wrench through cover and rotating shaft clockwise. Shaft should rotate freely. Replace pipe plug using a thread sealant.
- 6. Install air lines and test for proper operation.

C-3503-DM Rev.A Approved 7-29-04 Ken Thompson