

INSTALLATION INSTRUCTION FOR C-2533
FOR WILLIAMS VALVE WITH RESERVOIR

HW-6 Kit, C-2533 Cylinder, V-55 Valve,
TF-12-P Tubing & Fitting

PREPARE VALVE

1. Make sure valve is free from all foreign particles.
2. Remove the end spring cover using 1" wrench.

PREPARE CYLINDER

1. Remove two ¼ nuts from back of cylinder. This will disassemble cylinder into two parts:
 - a. Cylinder with two long cap screws
 - b. Spring cover with bracket.
2. Remove pipe plug from rear of cylinder using 3/16" allen wrench.

MOUNTING CYLINDER ON VALVE

1. Install spring cover with bracket on valve using 1" wrench.
2. Attach cylinder to valve by inserting 3/16" allen wrench through the hole in the rear cover plate, tighten firmly.
3. Push cylinder flush against spring cover. Attach with ¼" nuts on each side of bracket. Rotate bracket and cylinder to desired position then tighten firmly against spring cover.
4. Reinstall pipe plug in rear of cylinder using a thread sealant.
5. Install air lines and test for proper operation.

C-2533/HW-6 Kit Rev. - Approved 7-29-04 Ken Thompson
--